

VT440 / Dry contacts unit

Documentation page: <https://vutlan.atlassian.net/wiki/spaces/DEN/pages/35127335/VT440+Dry+contacts+unit>

Product page VT440: <https://vutlan.com/can-sensors/24-vt440-dry-contacts-unit.html>

Product page VT32: <https://vutlan.com/contacts/9-vt32-dry-contacts-board.html>



Order options

VT440 can be ordered in two options:

a) VT440 (x32 dry contact inputs)




b) VT440 + VT32 (x64 dry contact inputs)



Function and purpose

Allows increasing the number of dry contact inputs connected to any Vutlan monitoring unit. Adds 32 dry contacts. Can be connected to any CAN port on a CAN bus chain. Can be chained with other CAN sensors. The number of dry contacts inside VT440 can be increased up to 64 with an extension module "[VT32 / dry contacts module](#)".

Physical description



1. "**1...32**" - Dry contacts terminal.
2. "**33...64**" - Dry contacts empty slot. [VT32 / Dry contacts board](#) is ordered separately.
3. "**S/N**" - serial number. You will need this serial number if you want to contact our support team. It is important that you do not lose it!
4. LEDs: "**RUN**" - indicates appliance connection status to the main module, "**ERR**" - indicates appliance lost connection to the main module.
5. "**CAN 1**", "**CAN 2**" - two equivalent digital connectors RJ12 for the connection to the master module, CAN sensors, or CAN extensions on a CAN bus, with auto-sensing.
6. "**TR**" - is the nearest switch to CAN inputs. This switch should be turned "ON" on the last sensor in the CAN chain. The last sensor in the long chain with a length of more than 10 meters, terminator should be in "**OFF**" position.

Do not use DIP switch "FR" labeled "1", it should always be OFF. If this switch is turned ON, the module will turn off. This switch is only needed for programming purposes

Technical specifications




Feature	Description
Type	CAN sensor
Network interface	CAN open
Usage	Adds x32 dry contact inputs (digital inputs)
Product dimensions	(Width, Height, Depth) 215 x 40 x 40 mm
Power Consumption	1 Watt
Operating temperature	Optimal temperature range: -10° C to +80° C Extended temperature range: -40° C to +100° C

Mounting possibilities	19" rack-mountable Desktop Wall mount
Max. distance from the unit	225 m
Input terminals	Dry contacts / Digital inputs: 32 contacts RJ-12 ports: x2
Expansions (ordered separately)	"VT32 / Dry contacts board" - adds additional x32 contacts
Status Indicators	Red / Green Led
Operating humidity	0 to 95 %
Storage temperature	-40° C to +100° C
Storage humidity	0 to 95 %
Manufactured in (country)	Manufactured in Slovak Republic, E.U.
HS Code	8471 50 000
Daisy chain	Yes, possible


Package includes

Make sure that the contents of the delivery meet the following configuration. Report a missing or damaged component to your supplier. If damage occurred during transportation, contact the appropriate delivery service.

	Package content	Description
1		Dry contacts unit VT440.
2		RJ11 6P4C 2m cable


3		Self-adhesive rubber foot - 4 pcs
4		Terminal 6*3.5 mm - 8 pcs
5		Screws M3*8 - 6 pcs
6		19" rack brackets - 2 pcs.

Drawing




Installation

"TR" - is the nearest switch to CAN inputs. This switch should be turned "ON" on the last sensor in the CAN chain. The last sensor in the long chain with a length of more than 10 meters, terminator should be in "OFF" position.



pic.2.1: TR is ON, FR is OFF.



pic.2.2: TR is OFF, FR is ON.

CAN devices connection

CAN sensors and CAN units connection


1. Connect CAN devices to any port CAN1 or CAN2 on the monitoring system using a cable supplied. CAN sensors can also be connected to the port of another CAN sensor or CAN unit which is connected to the CAN bus. Determination of the devices and their connection is done through a web interface.



You can connect up to a maximum of x12 CAN sensors and CAN devices together on one CAN bus (approximately)!

If you want to connect more than x12 CAN units, you need to use [CAN-12V-1A / CAN Power Supply](#)

2. The TR should be "ON" for the last sensor on each bus "CAN 1" and "CAN 2". See section "TR" below.



This procedure applies to the following sensors, which are supported by the appliance and are connected to the CAN ports:

CAN sensors, modules:

- [VT408 / Extension unit](#)
- [VT430 / Rack control unit](#)
- [VT440 / Dry contacts unit](#)
- [VT460 / Smoke, humidity, and temperature...](#)
- [VT470 / PIR, vibration and temperature sensor](#)
- [VT490 / Humidity and temperature sensor](#)
- and other...

CAN extension unit:


- [VT408 / Extension unit](#)

Read more about [Setting up CAN sensors](#).

Used cable and limit line length

The maximum length of the CAN line in Vutlan monitoring systems is **225 m** due to limitations on the ohmic resistance of cables with RJ12 connectors.

It is advisable to use two or three pairs of cables such as UTP Cat3.5.6 with 24AWG with a copper core. It is possible to use a 4-wire or 6-wire TRONIC or UTP CCA cable, but the maximum CAN line length will be reduced.




TR termination switch

The last sensor TR switch on a CAN chain must always be terminated, (switched ON). Sensors on a CAN bus that is in the middle should have TR switched OFF.


FR should always be OFF.

TR switch is always the DP switch nearest to the CAN bus.

Only older Vutlan models have an FR switch.



pic.1.1: FR is OFF, TR is ON.



pic.1.2: FR is OFF, TR is OFF.

Adding CAN modules and sensors

To connect the CAN module or CAN sensor to the CAN bus of the system, go to the interface >> CAN configuration panel >> Select the CAN1 or CAN2 tab (select the connected physical CAN1 or CAN2 port on the master module).

Click the "Configure" button and wait. The system will start CAN bus polling, soon it will display the data lines and write "Done!". The modules and sensors connected to the CAN input will appear in a tab in the list. Click the Apply button and then Restart.

The green LED "CAN status" of the device will light up.

VUTLAN
Monitoring & Control Systems

operator

- Overall stats
- System tree
- Outlets
- Dry outputs
- Dry inputs
- Event log
- Logic schemes
- Cameras
- Map
- Users
- Access control
- CAN configuration**
- Graphs
- Reset smoke detectors
- Preferences
- System menu

CAN configuration


CAN 1

Network name: can0
State: up
Mode: normal
Last update time: 2020-05-13 8-42-42 PM

Product code	Description
VT440 (6)	32/64 dry contacts
VT460 (7)	Smoke, temperature, humidity
VT430 (10)	PIR sensor, 2 dry, humidity, temperature
VT490 (8)	Temperature, humidity
VT490 (8)	Temperature, humidity
VT490 (8)	Temperature, humidity
VT430 (10)	PIR sensor, 2 dry, humidity, temperature
VT430 (10)	PIR sensor, 2 dry, humidity, temperature
VT430 (10)	PIR sensor, 2 dry, humidity, temperature
VT430 (10)	PIR sensor, 2 dry, humidity, temperature

Refresh Save Configure Restart

Go to panel "System Tree" to see the new devices or new sensors. The article numbers for CAN devices are VT4xx. If they do not appear, wait, or refresh.



If after clicking the "Configure" button the poll is reset to the phrase "Update", then the line is not connected or the terminators on the bus are not agreed. It is necessary to check and change the condition of the **TR terminators** (See "TR termination switch" section above) on the modules or check and possibly change the **connection cables**.

Warning: If the bus is not matched, that is, there are bad contacts or bad cables, or the TR terminator is in the "ON" position on the intermediate devices (position 2 on the VT408), or the line is too short for matching on both CAN end devices, CAN on this line can work malfunctioning or the line as a whole may not function. (CAN line failure may occur if the parallel CR switch is in state 1, must be in OFF).

LEDs

CAN sensors have LEDs that indicate the following states:

- Red continuous light, green flickers - no communication with the master module
- Red continuous light, green is off - there is a connection with the master unit, but is not included in the monitoring system (not configured)
- Red is off, Green continuously light - work as part of a monitoring system
- All LEDs are off: no power or sensor is defective.

Maximum cable length test

Model	Description	50m	100m	150m	200m

VT408	Sensor extension unit		ok		
VT408DIN			ok		
VT430	Rack control unit		ok		
VT440	Dry contacts unit		ok		
VT460	Smoke, humidity, temperature		ok		
VT490 / VT490i	Dual humidity and temperature sensor / Pressure, humidity & temperature sensor		ok		

see also:

- [VT408 / Extension unit](#)
- [VT408DIN / Extension unit](#)
- [VT430 / Rack control unit](#)
- [VT440 / Dry contacts unit](#)
- [VT460 / Smoke, humidity, temperature sensor](#)
- [VT490 / Humidity and temperature sensor](#)
- [VT450 / Pressure, humidity and temperature sensor](#)
- [CAN-12V-1A / CAN Power Supply](#)

Setting up CAN

Enable CAN

Inside the web interface of the system go to >> Preferences menu >> Network tab >> Enable CAN >> Save >> Save settings to flash (An icon in the top right corner of the web interface)

Configuration

CAN bus is used for connection of CAN sensors and CAN modules. The device has two independent CAN nodes: CAN1 and AN2.

Before using CAN sensor module, CAN bus must be configured to operate with this CAN sensor module. To configure CAN bus go to "Main menu" >> "CAN" menu, which in turn has two identical tabs - one for each node.

CAN configuration username: guest

CAN 2

Network name can0

State up

Mode normal

Last update time 2015-02-04 9:26:29 AM

Product code	Description
sc470 (1)	Motion, vibration, temperature
sc408 (4)	8 analog (with auto detecting) sensors


Refresh **Save** **Configure** **Restart**

Each station tab contains current information on the status of the node and a list of CAN sensor modules connected to this node.

The following operations can be carried out on the CAN bus node:

- Refresh - updates the current information on the status of the node;
- Configure - launches configuration process of the nodes for CAN sensor modules connected to it, the old configuration is lost
- Save - saves the list of CAN sensor modules in flash memory;
- Restart - restarts the CAN bus node.

To delete a CAN sensor module, click on the desired module. A modal window will pop up. Press "Delete" and confirm.



To set up a CAN bus node for operation with the CAN sensor module, connect CAN module to CAN network and run corresponding configuration procedure in the web interface using the command "Configure". The configuration process is displayed at the bottom of the tab and lasts approx. 2 minutes. Detected modules will be added to the list of modules during the configuration process. After completing configuration the node returns to its normal operation. Sensors of detected CAN modules are added to the tree of elements.

The names of the sensors are automatically set in the form {module name}{serial number}-{type of sensor} and can be edited.

If you need to remove CAN sensor module from the configuration list use command Delete, then use command "Save" to apply the changes you made and restart the node using the command Restart.

- [Configuring VT408](#)

Copyright:

Vutlan s.r.o. (LLC)

Remote Infrastructure Monitoring and Control

43 ul.Svornosti, 821 06 Bratislava,

Slovak Republic

www.vutlan.com